

## PRODUCT ADVISORY

### 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses

#### ANSI & OSHA Versions

This is not a recall, the 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses remain safe for use. As part of 3M Fall Protection's ongoing commitment to delivering high quality safety equipment, we are notifying our customers of the following information related to the 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses portfolios. During internal testing of certain 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harness models, we found that a percentage of tested units did not meet the ANSI Z359.11, Section 3.2.2.3.1 dynamic requirement on the front (sternal) D-ring. This test and the resulting forces are not representative of what would be seen in real world application (i.e. when attached to a vertical cable sleeve with an energy absorbing device).



The 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses remain safe for use. In all tests, these harnesses meet all static requirements and dynamic testing that simulates a real-world application. Variability in the supplied D-ring contributed to the test results seen. This issue has been corrected on harnesses produced after May 1, 2021. We are not aware of any accidents, injuries, or customer complaints related to the condition described above.

Affected 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses can be found by accessing the link: <http://go.3M.com/XOHarnessSternalDRingAdvisory>

**End Users:** If this notice of non-compliance to the ANSI requirement is of concern to you, please inspect your Cross Over Style Harness label(s) (see photograph to right) to determine if it is one of the affected part numbers and was manufactured before May 1, 2021. Once you have confirmed the part number & affected date, please contact 3M Customer Service at 1-833-638-2697 or at [3musfpserviceaction@mmm.com](mailto:3musfpserviceaction@mmm.com) and provide us with contact information. We will have someone contact you to discuss the following remediation options:



1. Remediate your product(s) at your location.
  - 3M will ship D-ring sleeve(s) and instructions for application of the D-ring sleeve(s) directly to you at 3M's expense.
2. Return affected product(s) to 3M for remediation by 3M.
  - A UPS shipping label will be created for you to facilitate the return of your affected product(s).
  - Returned product must pass a pre-use inspection. If it passes the inspection, 3M will apply the D-ring sleeve(s) to your harness(es) and return the remediated product to you at 3M's expense. If it fails inspection, we will dispose of the product and contact you.

If you have any questions regarding this notice, please contact the 3M Fall Protection Customer Service Team at [3musfpserviceaction@mmm.com](mailto:3musfpserviceaction@mmm.com) or call 1-833-638-2697.

**Distributors:** Please contact our Customer Service department at 1-833-638-2697 or at [3musfpserviceaction@mmm.com](mailto:3musfpserviceaction@mmm.com) to obtain a listing of all affected 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harness(s) sold to you. Please forward this "Product Advisory" to any of your customers/users who have purchased the harnesses listed above from you. If you have any inventory of the affected models, please contact our Customer Service department to have them returned.

## PRODUCT ADVISORY

### 3M™ DBI-SALA® Delta™, ExoFit™, ExoFit™ Plus & ExoFit™ XP Cross Over Style Harnesses ANSI/OSHA Affected Part Numbers

| Part Number | Description              |                          |
|-------------|--------------------------|--------------------------|
| 1100235     | HARN QC OIL VD 2D SM     | 1246445,BT,SSTRP,EXOFIT  |
| 1100236     | HARN QC OIL VD 2D MED    | 1246445,BT,SSTRP,EXOFIT  |
| 1100237     | HARN QC OIL VD 2D LG     | 1246445,BT,SSTRP,EXOFIT  |
| 1100238     | HARN QC OIL VD 2D XL     | 1246445,BT,SSTRP,EXOFIT  |
| 1100264     | HARN QC OIL VD 2D XXL    | 1246445,BT,SSTRP,EXOFIT  |
| 1100690     | HARN TB CON XO 1D MED XP | 2 18"EXT,SEWN PAD,BELT   |
| 1100691     | HARN TB CON XO 1D LG XP  | 2 18"EXT,SEWN PAD,BELT   |
| 1100692     | HARN TB CON XO 1D XL XP  | 2 18"EXT,SEWN PAD,BELT   |
| 1100693     | HARN TB CON XO 1D SM XP  | 2 18"EXT,SEWN PAD,BELT   |
| 1100694     | HARN TB CON XO 1D XXL XP | 2 18"EXT,SEWN PAD,BELT   |
| 1100695     | HARN TB CON XO 1D 3XL XP | 2 18"EXT,SEWN PAD,BELT   |
| 1100696     | HARN QC XO 2D SM DC      |                          |
| 1100697     | HARN QC XO 2D MED DC     |                          |
| 1100698     | HARN QC XO 2D LG DC      |                          |
| 1100699     | HARN QC XO 2D XL DC      |                          |
| 1100700     | HARN TB XO 3DH D3 18"EXT | R SHLDR FASTNR           |
| 1100701     | HARN TB XO 3DH XL D3 18" | EXT,R SHLDR FASTNR       |
| 1100702     | HARN TB XO 3DH XXL D3    | 18" EXT,R SHLDR FASTNR   |
| 1100703     | HARN TB XO 3DH LG D3 18" | EXT,R SHLDR FASTNR       |
| 1100704     | HARN TB XO 4D MED DP     | H&L FASTNR               |
| 1100840     | HARN TB XO 6DHS D3       |                          |
| 1100841     | HARN TB XO 6DHS SM D3    |                          |
| 1100842     | HARN TB XO 6DHS XL D3    |                          |
| 1100885     | HARN QC XO 4DH SM DC     |                          |
| 1100886     | HARN QC XO 4DH MED DC    |                          |
| 1100887     | HARN QC XO 4DH LG DC     |                          |
| 1100888     | HARN QC XO 4DH XL DC     |                          |
| 1100924     | HARN TB CON XO 2D XS D2  |                          |
| 1100925     | HARN TB CON XO 1D SM D2  | 8035,910,4207,4097       |
| 1100926     | HARN TB CON XO 1D MED D2 | 8035,910,4207,4097       |
| 1100927     | HARN TB CON XO 1D XL D2  | 8036,910,4207,4097       |
| 1100928     | HARN TB CON XO 1D XXL D2 | 8036,910,4207,4097       |
| 1100929     | HARN TB CON XO 1D LG D2  | 8036,910,4207,4097       |
| 1101710     | HARN QC CON XO 2D MED XP | PAD,BELT                 |
| 1101711     | HARN QC CON XO 2D LG XP  | PAD,BELT                 |
| 1101712     | HARN QC CON XO 2D XL XP  | PAD,BELT                 |
| 1101800     | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S        |
| 1101801     | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S        |
| 1101802     | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S        |
| 1101804     | HARN PT CON XO 2D DP 18" | EXT,8035,910-3,4207,4097 |



|          |                          |                   |
|----------|--------------------------|-------------------|
| 1101805  | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S |
| 1101806  | HARN PT CON XO 2D XL D3  |                   |
| 1101807  | HARN PT CON XO 2D D3     | PAD,BELT          |
| 1101808  | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S |
| 1101809  | HARN PT CON XO 2D SM D3  | PAD,BELT,SIDE D'S |
| 1101810  | HARN PT CON XO 2D MED D3 | PAD,BELT,SIDE D'S |
| 1101811  | HARN PT CON XO 2D LG D3  | PAD,BELT,SIDE D'S |
| 1101812  | HARN PT CON XO 2D XL D3  | PAD,BELT,SIDE D'S |
| 1101813  | HARN PT CON XO 2D D3     | PAD,BELT          |
| 1101814  | HARN PT CON XO 2D D3     | PAD,BELT,SIDE D'S |
| 1101815  | HARN PT CON XO 2D D3     | PAD,BELT          |
| 1101816  | HARN PT CON XO 2D D3     | PAD,BELT          |
| 1101818  | HARN PT CON XO 2D XXL D3 | PAD,BELT,SIDE D'S |
| 1101819  | HARN PT CON XO 2D XS D3  | PAD,BELT,SIDE D'S |
| 1101820  | HARN PT CON XO 2D XS D3  |                   |
| 1101821  | HARN PT CON XO 2D 3XL D3 |                   |
| 1101822  | HARN PT CON XO 2D XXL D3 |                   |
| 1101823  | HARN PT CON XO 2D CSZ D2 |                   |
| 1101824  | HARN PT CON XO 1D DP 18" | EXT,H&L FASTNR    |
| 1101854  | HARN PT XO 2D XS D3      |                   |
| 1101855  | HARN PT XO 2D XL D3      |                   |
| 1101856  | HARN PT XO 2D XXL D3     |                   |
| 1101857  | HARN PT XO 2D 3XL D3     |                   |
| 1101858  | HARN PT XO 2D HV D3      |                   |
| 1101858H | HARN PT XO 2D HV D3,LOGO |                   |
| 1101859  | HARN PT XO 2D XS DP      | 3304LE1.2         |
| 1101860  | HARN PT XO 2D SM D3      |                   |
| 1101861  | HARN PT XO 1D D2         |                   |
| 1101862  | HARN PT XO 1D SM D3      |                   |
| 1101863  | HARN PT XO 1D DP 1' EXT  | SNAP FASTNR,4097  |
| 1101864  | HARN PT XO 2D LMG D2     |                   |
| 1101870  | HARN PT XO 1D XS D2      |                   |
| 1101871  | HARN PT XO 2D LG D3      |                   |
| 1101872  | HARN PT XO 2D SM LMG D2  |                   |
| 1101874  | HARN PT XO 2D XXS D2     |                   |
| 1102010  | HARN PT XO 2D D3         |                   |
| 1102900  | HARN PT CON XO 4DH D2    | PAD,BELT          |
| 1102901  | HARN PT CON XO 4DH D2    | PAD,BELT          |
| 1102903  | HARN PT CON XO 4DH D2    | PAD,BELT          |
| 1102904  | HARN PT CON XO 4DH XL D2 |                   |
| 1102905  | HARN PT CON XO 4DH D2    | PAD,BELT          |
| 1102907  | HARN PT CON XO 4DH XS D2 |                   |
| 1102908  | HARN PT CON XO 4DH D2    | PAD,BELT          |
| 1102911  | HARN PT CON XO 4DH XXL   | D2                |
| 1102912  | HARN PT CON XO 4DH 3XL   | D2                |
| 1102950  | HARN TB XO 2D D3         |                   |



|          |                          |                     |
|----------|--------------------------|---------------------|
| 1102950H | HARN TB XO 2D D3,LOGO    |                     |
| 1102951  | HARN TB XO 2D XXL D3     |                     |
| 1102952  | HARN TB XO 2D XL D3      |                     |
| 1102953  | HARN TB XO 2D DP         | 7010LDDP6           |
| 1102954  | HARN TB XO 2D C.SZ DP    |                     |
| 1102955  | HARN TB XO 2D 3XL D3     |                     |
| 1102956  | HARN TB XO 2D DP,18"EXT  |                     |
| 1102957  | HARN TB XO 2D XS D3      |                     |
| 1102959  | HARN TB XO 2D XS CH DP   |                     |
| 1102962  | HARN TB XO 2D SM DP,18"  | EXT                 |
| 1102963  | HARN TB XO 2D MED DP,18" | EXT                 |
| 1102964  | HARN TB XO 2D XL DP,18"  | EXT                 |
| 1102965  | HARN TB XO 2D XXL DP,18" | EXT                 |
| 1102966  | HARN TB XO 2D 3XL DP,18" | EXT                 |
| 1102972  | HARN TB XO 2D SM D3      |                     |
| 1102973  | HARN TB XO 2D LG DP,18"  | EXT                 |
| 1103250  | HARN PT XO 4D B DP       |                     |
| 1103251  | HARN PT XO 4DH XXL D3    |                     |
| 1103252  | HARN PT XO 4DH XL D3     |                     |
| 1103253  | HARN PT XO 4DH XS D3     |                     |
| 1103254  | HARN PT XO 4DH HV D3     |                     |
| 1103255  | HARN PT XO 4DH 3XL D3    |                     |
| 1103256  | HARN PT XO 4DH XS HV D3  |                     |
| 1103257  | HARN PT XO 4DH XL HV D3  |                     |
| 1103258  | HARN PT XO 4DH SM D3     |                     |
| 1103259  | HARN PT XO 4DH XXL HV D3 |                     |
| 1103260  | HARN PT XO 4DH CH D3     |                     |
| 1103261  | HARN PT XO 4DH XL CH D3  |                     |
| 1103262  | HARN PT XO 4DH XXL CH D3 |                     |
| 1103263  | HARN PT XO 4DH SM CH D3  |                     |
| 1103264  | HARN PT XO 4D D2 LMG     |                     |
| 1103265  | HARN PT XO 4DH 3XL HV D3 |                     |
| 1103266  | HARN PT XO 4DH LG CH D3  |                     |
| 1103267  | HARN PT XO 4D C.SZ D2    |                     |
| 1103270  | HARN PT XO 4DH D3        |                     |
| 1103350  | HARN TB TC XO 2D LG D2   | PAD,BELT,SEAT STRAP |
| 1103351  | HARN TB TC XO 2D MED D2  | PAD,BELT,SEAT STRAP |
| 1103352  | HARN TB TC XO 2D XL D2   | PAD,BELT,SEAT STRAP |
| 1103353  | HARN TB TC XO 2D XXL D2  | PAD,BELT,SEAT STRAP |
| 1103354  | HARN TB TC XO 2D 3XL D2  | PAD,BELT,SEAT STRAP |
| 1103355  | HARN TB TC XO 2D SM D2   | PAD,BELT,SEAT STRAP |
| 1103356  | HARN TB TC XO 2D SM D2   | PAD,BELT,SEAT STRAP |
| 1103357  | HARN TB TC XO 2D XS D2   | PAD,BELT,SEAT STRAP |
| 1103360  | HARN TB TC XO 2D MED D2  | PAD,BELT,SEAT STRAP |
| 1103375  | HARN TB XO 4DH D3        |                     |
| 1103376  | HARN TB XO 4DH XL D3     |                     |



|         |                          |                        |
|---------|--------------------------|------------------------|
| 1103377 | HARN TB XO 4DH HV D3     |                        |
| 1103378 | HARN TB XO 4DH MED D3    |                        |
| 1103379 | HARN TB XO 4DH LG D3     |                        |
| 1103380 | HARN TB XO 4DH D3 LMG    | ALCOA                  |
| 1103382 | HARN TB XO 4DH XS D3     |                        |
| 1103383 | HARN TB XO 4DH SM D3     |                        |
| 1103384 | HARN TB XO 4DH XXL D3    |                        |
| 1103385 | HARN TB XO 3DH 3XL D3    | 18" EXT,R SHLDR FASTNR |
| 1103386 | HARN TB XO 3DH XS D3 18" | EXT,R SHLDR FASTNR     |
| 1103393 | HARN TB XO 4DH XXL HV D3 |                        |
| 1103394 | HARN TB XO 3DH SM D3 18" | EXT,R SHLDR FASTNR     |
| 1103395 | HARN TB XO 4DH 3XL D3    |                        |
| 1103510 | HARN PT CON XO 4DH D2    |                        |
| 1103511 | HARN PT CON XO 2D D3     |                        |
| 1103824 | HARN TB CON XO 4D SM D2  | 8035,910-2             |
| 1103825 | HARN TB CON XO 4DH D2    |                        |
| 1103826 | HARN TB CON XO 4D D2     | 8035,910-3             |
| 1103827 | HARN TB CON XO 4DH XL D2 |                        |
| 1103828 | HARN TB CON XO 4D D2     | 8036,910-4             |
| 1103829 | HARN TB CON XO 4DH XXL   | D2                     |
| 1103831 | HARN TB CON XO 4DH SM D2 |                        |
| 1103836 | HARN TB CON XO 4DH NB D2 |                        |
| 1103837 | HARN TB CON XO 4D 3XL DP | 1225177 ATTACHED       |
| 1103838 | HARN TB CON XO 4D XXL NB | D2                     |
| 1103839 | HARN TB CON XO 4D 3XL NB | D2                     |
| 1104850 | HARN TB CON XO 2D D2     |                        |
| 1104851 | HARN TB CON XO 2D LG D2  |                        |
| 1104852 | HARN TB CON XO 2D XL D2  | 8036,910-5,4207        |
| 1104853 | HARN TB CON XO 2D MED D2 | 8035,910-3,4207        |
| 1104854 | HARN TB CON XO 2D LG D2  | 8036,910-4,4207        |
| 1104855 | HARN TB CON XO 2D XL D2  |                        |
| 1104856 | HARN TB CON XO 2D XXL D2 | 8036,910-6,4207        |
| 1104857 | HARN TB CON XO 2D SM D2  | 8035,910-2,4207        |
| 1104860 | HARN TB CON XO 2D XL D2  | 8036,910-5             |
| 1104861 | HARN TB CON XO 2D XXL D2 |                        |
| 1104863 | HARN TB CON XO 2D SM D2  |                        |
| 1104871 | HARN TB CON XO 2D MED D2 |                        |
| 1104874 | HARN TB CON XO 2D NB D2  |                        |
| 1105725 | HARN TB CON XO 2D LG DP  | 901-4                  |
| 1105726 | HARN TB CON XO 2D MED DP | 901-3                  |
| 1105727 | HARN TB CON XO 2D XL DP  | 901-5                  |
| 1105729 | HARN TB CON XO 2D SM DP  | 901-2                  |
| 1105730 | HARN TB CON XO 2D LG DP  | 901-4,9501945          |
| 1105731 | HARN TB CON XO 2D XL DP  | 901-5,9501945          |
| 1105732 | HARN TB CON XO 2D LG DP  | 18"EXT,901-4           |
| 1105733 | HARN TB CON XO 2D XL DP  | 18"EXT,901-5           |

|          |                          |                          |
|----------|--------------------------|--------------------------|
| 1105734  | HARN TB CON XO 2D MED DP | 18"EXT,901-3             |
| 1105735  | HARN TB CON XO 2D SM DP  | 18"EXT,901-2             |
| 1106180  | HARN TB CON XO 2D MED    | HVR D3,PAD,BELT,S STRAP  |
| 1106375  | HARN TB CON XO 1D LG DP  | 18"EX,1D BELT,S FST,4207 |
| 1106376  | HARN TB CON XO 1D 3XL DP | 18"EXT,1D BELT,SNP FSTNR |
| 1106377  | HARN TB CON XO 1D LG DP  | 18"EXT,1D BELT,SNP FSTNR |
| 1106378  | HARN TB CON XO 1D XL DP  | 18"EXT,1D BELT,SNP FSTNR |
| 1106379  | HARN TB CON XO 1D XXL DP | 18"EXT,1D BELT,SNP FSTNR |
| 1106380  | HARN TB CON XO 1D XL DP  | 18"EX,1D BELT,S FST,4207 |
| 1106381  | HARN TB CON XO 1D XXL DP | 18"EX,1D BELT,S FST,4207 |
| 1106382  | HARN TB CON XO 1D SM DP  | 18"EX,1D BELT,S FST,4207 |
| 1106383  | HARN TB CON XO 1D MED DP | 18"EX,1D BELT,S FST,4207 |
| 1106384  | HARN TB CON XO 1D MED DP | 18"EXT,1D BELT,SNP FSTNR |
| 1106385  | HARN TB CON XO 1D SM DP  | 18"EXT,1D BELT,SNP FSTNR |
| 1106386  | HARN TB CON XO 1D 3XL DP | 18"EX,1D BELT,S FST,4207 |
| 1106425  | HARN TB XO 4D DP 18"EXT  | R SHLDR FASTNR           |
| 1106426  | HARN TB XO 4D XL DP      | 18" EXT,R SHLDR FSTNR    |
| 1106427  | HARN TB XO 4D XXL DP     | 18" EXT,R SHLDR FSTNR    |
| 1107150  | HARN TB CON XO 2D LG DP  | 14"EXT,1D BELT LG        |
| 1107151  | HARN TB CON XO 2D XL DP  | 14"EXT,1D BELT XL        |
| 1107152  | HARN TB CON XO 2D SM DP  | 14"EXT,1D BELT SM        |
| 1107153  | HARN TB CON XO 2D MED DP | 14" EXT,1D BELT MED      |
| 1107154  | HARN TB CON XO 2D XXL DP | 14"EXT,1D BELT XXL       |
| 1108025  | HARN PT CON XO 2D 3XL D3 | PAD,BELT,SIDE D'S        |
| 1108026  | HARN PT CON XO 2D SM D3  |                          |
| 1108029  | HARN PT CON XO 2D DP 18" | EXT,8036,910-4,4207,4097 |
| 1108033  | HARN PT CON XO 1D 3XL DP | 3300LDP6,8036,910-7,4207 |
| 1108034  | HARN PT CON XO 1D 3XL DP | 3700LDP6,8036,910-7,4207 |
| 1108358  | USE 1108358C             |                          |
| 1108675  | HARN QC XO 2D SM EXOFIT  |                          |
| 1108675H | HARN QC XO 2D SM EXOFIT  | LOGO                     |
| 1108676  | HARN QC XO 2D MED EXOFIT |                          |
| 1108676H | HARN QC XO 2D MED EXOFIT | LOGO                     |
| 1108677  | HARN QC XO 2D LG EXOFIT  |                          |
| 1108677H | HARN QC XO 2D LG EXOFIT  | LOGO                     |
| 1108681  | HARN QC XO 2D XS EXOFIT  |                          |
| 1108682  | HARN QC XO 2D XL EXOFIT  |                          |
| 1108682H | HARN QC XO 2D XL EXOFIT  | LOGO                     |
| 1108683  | HARN QC XO 2D XXL EXOFIT |                          |
| 1108700  | HARN QC XO 4D SM EXOFIT  |                          |
| 1108700H | HARN QC XO 4D SM EXOFIT  | LOGO                     |
| 1108701  | HARN QC XO 4D MED EXOFIT |                          |
| 1108701H | HARN QC XO 4D MED EXOFIT | LOGO                     |
| 1108702  | HARN QC XO 4D LG EXOFIT  |                          |





|          |                          |                |
|----------|--------------------------|----------------|
| 1108702H | HARN QC XO 4D LG EXOFIT  | LOGO           |
| 1108704  | HARN QC XO 4D SM EXOFIT  | 18"EXT,S FSTNR |
| 1108706  | HARN QC XO 4D XL EXOFIT  |                |
| 1108706H | HARN QC XO 4D XL EXOFIT  | LOGO           |
| 1108707  | HARN QC XO 4D XS EXOFIT  |                |
| 1108707H | HARN QC XO 4D XS EXOFIT  | LOGO           |
| 1108708  | HARN QC XO 4D XXL EXOFIT |                |
| 1108708H | HARN QC XO 4D XXL EXOFIT | LOGO           |
| 1109040  | HARN PT XO 2D SM HV D3   |                |
| 1109050  | HARN PT XO 4DH D3,18"EXT |                |
| 1109052  | HARN PT XO 4DH LG D3     |                |
| 1109060  | HARN PT XO 4D XXS D2     |                |
| 1109062  | HARN PT XO 4DH D3        |                |
| 1109063  | HARN PT XO 4D XL D2 LMG  |                |
| 1109064  | HARN PT XO 4DH DP        |                |
| 1109400  | HARN PT XO 2D XL HV D3   |                |
| 1109800  | HARN QC XO 2D SM XP      |                |
| 1109801  | HARN QC XO 2D MED XP     |                |
| 1109802  | HARN QC XO 2D LG XP      |                |
| 1109803  | HARN QC XO 2D XL XP      |                |
| 1109807  | HARN QC XO 2D XXL XP     |                |
| 1109808  | HARN QC XO 2D SM XP,18"  | EXT            |
| 1109809  | HARN QC XO 2D MED XP,18" | EXT            |
| 1109810  | HARN QC XO 1D XS XP      |                |
| 1109811  | HARN QC XO 1D XL XP      |                |
| 1109812  | HARN QC XO 2D XS XP      | ID LABEL       |
| 1109813  | HARN QC XO 2D SM XP      | ID LABEL       |
| 1109814  | HARN QC XO 2D MED XP     | ID LABEL       |
| 1109817  | HARN QC XO 1D XXL XP     |                |
| 1109818  | HARN QC XO 2D XS XP      |                |
| 1109825  | HARN TB XO 4D SM EXOFIT  |                |
| 1109826  | HARN TB XO 4D MED EXOFIT |                |
| 1109827  | HARN TB XO 4D LG EXOFIT  |                |
| 1109828  | HARN TB XO 4D XL EXOFIT  |                |
| 1110350  | HARN QC XO 4D SM XP      |                |
| 1110351  | HARN QC XO 4D MED XP     |                |
| 1110352  | HARN QC XO 4D LG XP      |                |
| 1110353  | HARN QC XO 4D XL XP      |                |
| 1110354  | HARN QC XO 4D XS XP      |                |
| 1110355  | HARN QC XO 4D XXL XP     |                |
| 1110700  | HARN QC XO 2D D3         |                |
| 1110701  | HARN QC XO 2D SM D3      |                |
| 1110702  | HARN QC XO 2D XL D3      |                |
| 1110704  | HARN QC XO 2D XS D3      |                |
| 1110725  | HARN QC XO 4DH D3        |                |
| 1110726  | HARN QC XO 4DH SM D3     |                |



|         |                        |      |
|---------|------------------------|------|
| 1110727 | HARN QC XO 4DH XL D3   |      |
| 1112250 | HARN TB XO 2D TEAL D2  |      |
| 1112375 | HARN QC XO 2D XXL D3   |      |
| 1112376 | HARN QC XO 2D MED D3   |      |
| 1112377 | HARN QC XO 2D LG D3    |      |
| 1112401 | HARN QC XO 4DH MED D3  |      |
| 1112402 | HARN QC XO 4DH LG D3   |      |
| 1112404 | HARN QC XO 4DH XXL D3  |      |
| 1140096 | HARN QC XO 4DH XS EXO  | PSRL |
| 1140097 | HARN QC XO 4DH SM EXO  | PSRL |
| 1140098 | HARN QC XO 4DH MED EXO | PSRL |
| 1140099 | HARN QC XO 4DH LG EXO  | PSRL |
| 1140100 | HARN QC XO 4DH XL EXO  | PSRL |
| 1140101 | HARN QC XO 4DH XXL EXO | PSRL |